

SPAN Furniture

Cleaning Instructions

To maintain the quality and appearance of Savaria's Casegoods products, it is recommended to use mild cleaning agents:

Mild Soap and Water: A mixture of mild dish soap and water is safe and effective for everyday cleaning.

Vinegar and Water: Equal parts vinegar and water can be used to cut grease and grime.

Baking Soda and Vinegar: For tougher stains, mix into a paste.

General Cleaning Instructions

- Gently wipe surfaces with a soft cloth or sponge and mild soap/water.
- Avoid continuous or heavy scrubbing.
- Do not spray cleaning products directly-apply to a cloth or sponge first.
- Diluted rubbing alcohol or a small amount of Dawn dish soap or Simple Green® (50/50 with water) can remove ink stains and act as a degreaser.
- Use 20-30 gentle strokes with a soft cloth to remove most stains.

Disinfecting Surfaces

- Clean dirt from surfaces before disinfecting.
- Use 20 ml of bleach to 1 liter of water.
- Use disposable gloves and test on a hidden spot first.
- If using reusable gloves, dedicate them solely for disinfecting.
- Never mix bleach with ammonia.

Heat Exposure Guidelines

- Avoid excessive heat and steam.
- Do not place appliances that generate high heat or steam directly under cabinet doors or any furniture products.
- When using a self-cleaning feature on an oven, open all adjacent doors and install a heat shield between drawer/door fronts and the oven to prevent heat damage.

Products to Avoid - Use Will Void Warranty:

- | | | |
|-------------|--------------------------|---|
| • Abrasives | • Solvent-based cleaners | • Powdered cleansers |
| • Ammonia | • Wood preservatives | • Paper towels |
| • Acetone | • Scouring pads | • Methylated spirits |
| • Acids | • Quaternary cleaners | • Harsh chemicals (e.g., sink and toilet bowl cleaners) |
| • Thinners | • Brushes | |